

NASA TECH BRIEF

Langley Research Center



NASA Tech Briefs announce new technology derived from the U.S. space program. They are issued to encourage commercial application. Tech Briefs are available on a subscription basis from the National Technical Information Service, Springfield, Virginia 22151. Requests for individual copies or questions relating to the Tech Brief program may be directed to the Technology Utilization Office, NASA, Code KT, Washington, D.C. 20546.

Wide Deviation Phase Modulator




Figure 1. Functional Diagram of Phase Modulator

A modulator was designed to produce a phase-modulated (PM) waveform having high modulating linearity. Practical circuits utilizing the technique described have been constructed and evaluated for peak phase deviations as large as 5 radians. Additionally, the technique is inherently wideband with respect to carrier frequency and can operate over a decade carrier frequency range without adjustments. Circuit performance is both mathematically predictable and highly reproducible.

Mathematically, an ideal PM waveform may be expressed as

$$e(t) = \text{Re} \left\{ A e^{j[\omega t + \Psi(t)]} \right\} \quad (1)$$

where A is the carrier amplitude, ω is the carrier radian frequency, and $\Psi(t)$ is the modulating function. Equation 1 can be rewritten as either

$$e(t) = [A \cos \omega t \cos \Psi(t)] - [A \sin \omega t \sin \Psi(t)] \quad (2)$$

$$\begin{aligned} \text{or} \\ e(t) = A \left[1 - \frac{\Psi^2(t)}{2!} + \frac{\Psi^4(t)}{4!} - \dots \right] \cos \omega t \\ - A \left[\Psi(t) - \frac{\Psi^3(t)}{3!} + \frac{\Psi^5(t)}{5!} - \dots \right] \sin \omega t \end{aligned} \quad (3)$$

The configuration shown in Figure 1 performs the operations indicated in equations 2 and 3. Sine and cosine modules are commercially available; however, they are at present two-quadrant ($\pm 90^\circ$) devices. This technique uses truncated power series processors and determines the coefficients for producing the best modulating linearity. The modulated phase of $e(t)$, $\varphi_0(\Psi)$, is

$$\varphi_0(\Psi) = \tan^{-1} \left[\frac{\Psi - k_3 \Psi^3 + k_5 \Psi^5 - \dots}{1 - k_2 \Psi^2 + k_4 \Psi^4 - \dots} \right] \quad (4)$$

(continued overleaf)

